



16-013

## LO-PRO LIFT KIT

WILL FIT CLUB CAR® PRECEDENT®

INSTALLATION INSTRUCTIONS

### INCLUDED:

LIFT BLOCK

4 M10X50 HEX HEAD BOLTS

4 M10 FLAT WASHERS



Lift Block

1

Place RUN/TOW switch in TOW position.  
Chock wheels and lift cart.



2

Place cart on jack stands as shown.



Remove the plate by removing the four factory bolts as shown.

3

Pry the leaf spring away from the cart to allow enough clearance for the lift block.



4



Place lift block between leaf spring and frame.

5

Attach plate using supplied hardware.



6