



780 Professional Drive N. Shreveport, LA 71105 Phone (318)-524-2270 Fax (318)-524-2297
www.highlifter.com

Can-Am Maverick X3 Tow Plate

Installation Instructions

1. Remove the nuts that secure the rear cover plate and radius bars to the frame.



2. Place the new tow plate onto the factory bolts.



3. Secure the tow plate to the frame using the factory nuts.

