

INSTALLATION INSTRUCTIONS YAMAHA DRIVE SERIES 2007 + PART NUMBER SSYHDR07



1.) Remove hip restraints and mounting hardware from stock seat base.



2.) Install hip restraints on seat base using the 8 stock bolts just removed. Install hinge tabs on seat base using provided M6 - 4cm hex head bolts and washers. *IMPORTANT* Hand start all bolts to prevent damage to tnuts. Seat base can now be installed on cart.



3.) Remove stock seat back.



4.) Using the M6 - 8 cm hex head bolts and washers provided, install seat backs. Start by placing 1 spacer on each side of seat back mount then sliding bolts through spacers and into seat backs. (Figure 3) Spacers should be placed to provide clearance for bolts that protrude from cart basket. *IMPORTANT* Start all bolts by hand to prevent damage to t-nuts.

REVISED SEPTEMBER 10, 2014 FOR METRIC HARDWARE